

Instructions for assembling Plinko Board.

1. Lay out all the pieces of the kit separately.
2. Lightly sand the dowels for a smooth top. Add a dab of wood glue to the bottom of each dowel and place into your pre-determined peg holes.
3. Place the section dividers along the marked pencil lines.
4. Glue section dividers.
5. Wait 30 mins for glue to dry.
6. Place against a wall and plink away!!!